


Installation of Pop up CNFPOP

Presentations Pop-up walls for fast and easy set up. Especially suitable for full-color prints and signs. Comes with lighting system and a transportation bag. Deliverable in two sizes.



Pop-up

3x3 POP-UP 275X226 cm
3x4 POP-UP 350X226 cm



The Pop-up presentation walls are delivered in a cart board box.



Do not open the box with a knife or sizzers!!! You might damage the suitcase.



In the packaging you find the transportation suitcase.



On the backside of the suitcase there is a grip which you can pull out, by tilting the suitcase you can easily roll the suitcase.




Open the suitcase by turning the openers on both sides
Content see image 6.



- 1x Pop-up wall
- PVC sheets (3x3=5 pieces 4x3=6 pieces)
- 2x Halogen lamp complete
- Connection peices (3x3=18 pieces 4x3=21 pieces)
- 1x Roll self adhesive magnetic tape
- Transportation suitcase
- hanging block (3x3=6 pieces 4x3=7 pieces)
- Hanging strips with slot (3x3=5 pieces 4x3=6 pieces)
- Hanging strips with cut-out piece (3x3=5 pieces 4x3=6 pieces)




The lamps are in the lid.




Lay down the Pop-up in such a way that the side with the 4 or 5* thick blocks on a row is on top, this will be the front side.
*4 or 5 depending on 3x3 or 3x4



Pull up the system half way, now you can easily mount the other pieces.




This is a thick block on the top side.




Pull up the system so that it unfolds completely.




These are the hanging strips with slot and with cut-out piece.




The hanging strip with slot comes on top of the PVC sheet, the hanging strip with cut-out piece on the bottom.



The hanging strips with slot and with cut-out piece are delivered in 2 lengths. The short ones are for the outside sheets of the wall (the curved sheets).



The system is delivered with a 3-pole plug, possibly you have to replace this one with another plug.



Mount the shoes on top of the thick blocks in the middle of the system.



Slide the halogen lamp over the shoe.



Make sure that the halogen lamp is firmly attached.




Aim the light on the presentation wall.



The light switch is located on the back of the Halogen lamp.



Repeat step 16 till 20 for the second Halogen Lamp.




You can also mount the halogen lamps on the legs of the system as shown. The light will be closer to you presentation.



Connection pieces




First place a connection piece on the bottom.



Slide the block on to the bottom block of the pop-up with the metal pin.



Take another connection piece and slide the point into the top block of the pop-up.



Slide the bottom block of the connection piece on the block below of the pop-up.




Slide the middle connection piece into the top connection piece block and the bottom connection piece into the middle connection piece block. Now slide the block onto the block with the metal pin of the pop-up.



One standing piece is now complete, repeat step 26 till 30 for the other standing pieces.




Attention: the PVC sheets are oversized!!! And have to be cut to the right size. The breadth of the hanging strip determines the breadth of the image.




Here you see clearly that the PVC sheet is wider than the hanging strip. This is done to make mounting the full-colour-print easier. The length you should measure in the system.



Mount the full-colour-print on the PVC sheet.




After mounting cut away the unnecessary strips.



Now that the full-colour-print is mounted and cut, the sheet has the breadth of the particular hanging strip.




The hanging strip with slot you put on the topside of the sheet, the hanging strip with cut-out piece on the bottomside. Mounting is done by the self adhesive strip.



Now mount on the backside of sheet the self adhesive magnetic strip on the long sides of the sheet.



Now the sheet is ready.



Hang the PVC sheet in the hanging blocks on the top-side.



The sheet stays in place by means of the magnetic strips and the hanging strips. Repeat the procedure for the other sheets.

